




Maypole Bells



Un-packing instructions

1. Lay the box flat on the floor near the fitting location and remove the bottom corner protectors (PZ2 screws)
2. Stand the box up with the MDF panels uppermost
3. Remove **one** MDF cover (PZ2 screws)
4. Remove top travel corner protectors (PZ2 screws)
5. Carefully cut off the black protective plastic
6. Remove the bubble wrapped packets (2 pulleys, computer wires, screws, brackets, and wall packer) Place safely to avoid standing on.
7. Remove 2nd cover (PZ2 screws)
8. Unbolt the travel locking bolt and remove the ceiling pully batten. (The dumbbell weight will be at the bottom (13mm spanner or grips) NOTE: the wheel will now be free flowing



9. Take out the Sally and unwrap
10. If you drop anything into the bell box carefully tip it up to shake the item out. **THE WHEEL IS NOW FREE TURNING.** Instructions for removing and replacing the wheel are in the installation guide

Health, Safety & Environmental:

- Take care when lifting. The bell weighs 22.2kg and is bottom heavy
- Do not place fingers through the spokes (should you need to raise the weight to the top placing a piece of wood through the spokes will temporarily hold it in place)
- Dispose of packaging as per your local rules (MDF, bolt and screws can be reused)